

Weather Report

Complete the Weather report using the slider to select the appropriate conditions at the time of your inspection.


Click 'Next' once all are set correctly.

 Inspections 


New Inspection

Step 3: Weather Conditions


Precipitation


Dry Drizzle Heavy Sleet Snow


Wind


Still Light Strong


Cloud / Sun


Sunny Broken Full

Ground Conditions


Dry Damp Frost Snow

Railhead Condition


Dry Wet



BackNext

Revision #1

Created 30 July 2025 09:13:26 by Simon Gilhooly

Updated 30 July 2025 09:15:49 by Simon Gilhooly